

HYVE GROUP requirements to the equipment set up and demonstration


1. All the equipment parts including extendable parts during its demonstration must be kept within the space of your rented stand.



2. The exhibitor is obliged to install protective fencing, screens etc. to ensure the safety of exhibitors and visitors when presenting the exhibit.



3. All the equipment parts that have open sharp, stabbing, cutting surfaces (whether they move or not) must be covered with appropriate protective casing (covers, pads, etc.) to prevent injury to exhibitors and visitors.



4. Demonstration of equipment in action is permitted only by a trained operator controlling the specified equipment. It is forbidden to leave working equipment at the stand without supervision of the machine operator.



5. To ensure the safety of visitors equipment exhibited in action shall be placed at a distance of at least 1.0 m from the stand borders. If you plan to demonstrate the equipment in action, you must inform the Organizer in advance.
In case of violation of the requirements specified in the permit, the Organizer reserves the right to suspend the demonstration of equipment